

CHOCOLATE PEANUT BUTTER MUFFINS

THAT'S
SMART![®]

Prep Time: 15 min

Bake Time: 16-18 min

Total time: about 30 min

Makes 6 muffins

Ingredients

¼ cup That's Smart!
Creamy Peanut Butter

1 That's Smart!
Large Egg

That's Smart! Raw
Spanish Peanuts,
chopped

¼ cup That's Smart! 2%
Reduced Fat Milk

1 package (6.5 ounces)
That's Smart! Chocolate
Chip Muffin Mix

Directions

1. Preheat oven to 375°F. Line 6 wells of a standard-size muffin pan with paper liners.
2. In a bowl, whisk together the peanut butter, milk, and egg. Add the muffin mix and stir just until moistened.
3. Divide batter evenly among the prepared muffin cups and sprinkle peanuts on top.
4. Bake for 16 to 21 minutes, or until a toothpick inserted in the center comes out clean. Cool muffins in the pan for 5 minutes, then transfer to a rack to cool completely.

